

# S-GO Video Remote Control Guide

**Input**

Choose between TV connections

**Setup**

Use to program remote control

**Device Selection\*\***  
Choose between your set top box, TV, or auxiliary device

**Lang**

Turns closed captioning on and off

**Vol + / -**

Adjust volume

**Guide**

Displays channel guide

**Playback Controls**

Control functions of Video On Demand and PVR

**Arrow Keys**

Scroll in guide and menus

**\*\*You must press the STB device button to put the remote control in the mode that controls your S-GO service.**

**Press the TV device button to put the remote control in TV mode.**



**Power**

Turns devices on or off

**Info**

Display Info bar

**Menu**

Display the Menu Bar

**Exit**

Exit current screen

**CH up / down**

Changes the channel

**Last**

Return to the last viewed channel

**Record**

Begin PVR recording

**OK**

Select function, enter a choice you have made

**Number Pad**

Enter channel numbers or PIN

**Mute**

Turn sound on or off

To program your remote control to your television, please refer to the instruction pamphlet provided with your equipment.

**Technical Support  
776-5500, opt 2**

The remote control must be in STB mode to change channels or access guide.